


Rolleiflex

IN PRACTICAL USE

THE QUICK BASIC PRINCIPLE



TO LOCATE THE MOST IMPORTANT PARAGRAPHS QUICKLY

Page:

- 6 **I. A Brief Rolleiflex-Anatomy**
- 10 The Automatic Film Transport Mechanism
- 12 **II. Rolleiflex in Operation**
- 12 Eveready Case
- 12 Lens Cap
- 14 Holding the Camera
- 16 Focusing Hood
- 16 Focusing Magnifier
- 17 Direct View Finder
- 18 Focusing
- 18 Diaphragm
- 19 Depth of Field
- 24 Shutter and Shutter Release
- 26 Self-Timer
- 26 Exposure
- 27 Auxiliary Focusing Knob

Page:

- 28 **III. Loading and Film Transport**
- 28 Back
- 30 Inserting the Film Spool
- 32 Thread the Film Leader
- 32 Film Transport
- 35 **IV. Flashlight-Technique**
- 38 Flash-Photography Tips
- 40 **V. Tips on Picture-Taking**
- 40 Landscapes
- 42 Portraits
- 43 Children
- 43 Animals
- 44 Snapshots
- 45 Sports
- 46 Theatre and Music-Hall
- 46 Night
- 47 Copying

Page:


- 48 Reflecting Surfaces
- 49 Plants
- 49 Color Pictures
- 50 Panoramas
- 50 Stereo
- 52 Micro Photography
- 52 Care of Camera
- 52 In Case of Damage to the Camera

Tables:

- 21 Depth of Field
- 23 Speed of Moving Objects and Shutter Speed
- 36 Flash-contact and Shutter Speed
- 53 Practical Accessories
- 54 Rollei Filters
- 55 Rolleinars

This Rolleiflex instruction book offers you the basic information necessary for the use of the camera. Practical matters of technique are adequately discussed, usually in the form of concise tips covering the most important phases of picture taking. Easy to use, highly informative tables are also included. It will therefore remain a source of information of permanent value to you.

Important: Before attempting to use or handle the camera we urge you to read carefully pages 12, 16, 24 and 28.



I. A BRIEF ROLLEIFLEX-ANATOMY

The Automatic Rolleiflex is a camera characterized above all by two special design features: the rigid construction of the twin lens reflex and the automatic film transport mechanism. These technical advantages do not form merely a basis for very high performance but at the same time contribute materially to the simplicity and ease of use for which the Rollei is justly famous.

It takes but a glance at the construction of the camera to recognize the simple elements of its practical operation.

Construction of the Twin Lens Reflex

In the Rolleiflex two separate cameras are joined in a twin-camera with a common sturdy die-cast body: the bottom half is the

taking-camera, in which the film is exposed, and the upper half is the


viewing-camera, which is designed on the mirror-reflex principle. Its special task is to make the focusing

visible on the ground glass and to supply a control image essentially similar to that of the prospective picture.

The image forming rays are transmitted by the fully open viewing lens, projected on to the ground glass screen via the mirror and the result is a right-side-up, but laterally reversed ground glass image, in the full size of the original picture. This viewing image is visible at all times and every detail of composition and framing may be watched even during exposure.

The ground glass screen is ruled with a number of vertical and horizontal lines making it possible to detect errors, such as lines which converge but should be parallel or a slanting horizon, in time to notice and correct them. It is easy to straighten or level the camera by means of the lines on the the ground glass screen.

Above all, the ground glass screen provides the means for **focusing the camera**. This is accomplished by rotating the focusing knob. Both lenses, which are inflexibly coupled to each other by means of a sturdy common front plate, are thereby adjusted simultaneously: a sharp viewing image therefore guarantees an equally sharp picture. Since the Rolleiflex is equipped with a fast viewing lens and an optically prepared ground glass screen, the viewing






image is extremely bright and clear and focusing can be done very critically.

The **focusing hood**, which is designed for one-hand operation, is kept in both open and closed positions by spring tension. It is equipped with a **magnifier** offering approximately 2.5 times magnification for critical focusing.

The rectangular magnifier flap also acts as a shield for the focusing hood and prevents extraneous light from above reaching the viewing image.


If the front panel of the focusing hood is pushed inward, it is transformed into a **direct view finder** through which the subject may be seen in natural size making it particularly easy to follow fast action. In this case it is still possible at all times to maintain control over focus: this is made possible by means of a second magnifier in the back of the focusing hood, and a diagonally mounted mirror. A slight raising or lowering of the Rolleiflex is all that is required to alternate between the right-side-up open view in the direct finder, and the reversed center portion of the ground glass focusing image. The fact that the two finder openings are located so close together, enables quick framing of the subject after focusing. The usefulness of the open direct view finder is thereby enhanced for sports pictures.

Focusing the front lens panel throughout the range from $2\frac{2}{3}$ ft— ∞ (infinity) is accomplished by one full turn of the focusing knob. The special design of the focusing mechanism (a cam-drive based on the principle of the archimedic spiral) insures uniform movement of the lens panel in both directions without play or backlash.

Tied in with the movement of the lenses is a simple sliding mechanism, located beneath the ground glass, providing completely automatic **parallax compensation**. Consequently, the final picture is always framed exactly as originally viewed on the ground glass screen. Similarly complete control can be had even when using supplementary Rolleinar lenses for close-up work merely by adding the Rolleipar.

Diaphragm openings and **shutter speeds** are regulated by means of the small knurled wheels located on each side of the lens panel, and the control scales are visible in the single window seen at the top of the panel. Thus, all manipulations take place with the camera in operating position and are easily checked with but a single glance.

Since the two **lenses** are of identical focal length ($f=75$ mm) it follows that the image in both sections of the camera will always be critically focused on the same portion of the subject simultaneously.



The f:3.5 taking lens is a four glass construction with two cemented elements (modified Taylor-type) and features outstanding correction for black and white- and color pictures, while the three-element viewing-lens f:2.8 meets with the special requirements for best ground glass focusing. Both lenses are treated with abrasion resistant coating. The bayonet receptacles circling the mounts are intended for attaching the lens hood and supplementary optical accessories, which in this way will be held in optically correct position and form a solid unit with the camera.

The removable **combination back** is attached to the camera by means of hinges fitted with locking clips, and at the bottom it contains the tripod socket and the safety back lock. Its adaptability for the two picture sizes $2\frac{1}{4} \times 2\frac{1}{4}$ ", and 24×36 mm is the result of the adjustable film pressure plate which can be set for 120 (B II 8)-film (with paper backing), or for 35 mm film (without paper backing) when used in conjunction with the Rolleikin II attachment. In both cases a film channel is created with a width that corresponds to the thickness of the film being used. Thus the film can be properly held in the focal plane, and also can slide through without undue friction when advanced.

The Automatic Film Transport Mechanism

The constant readiness of the Rolleiflex, a natural result of its advantageous twin-lens design, is further enhanced by the automatic film transport mechanism. The quick acting **crank** coupled with an automatic gear mechanism performs six important functions with each pendulum swing:

1. Advances film to next frame
2. Advances film frame counter
3. Tensions the shutter
4. Resets the self-timer mechanism
5. Releases shutter lock
6. Engages film lock.

The shutter release and film advance crank are locked and unlocked alternately, thereby offering full insurance against double exposures or skipped frames.


Automatic stops limit the extent of crank swing. With the increasing thickness of the film on the take-up spool the crank swing decreases from $\frac{3}{4}$ of a turn in the beginning to just under $\frac{1}{2}$ turn at the end

of the roll. Thus the film is always advanced exactly one full frame.

In addition to this, each swing of the crank automatically brings up the next number in the film counter window.

The positioning of the film so that the first frame is correctly placed also is accomplished automatically. After inserting the full film spool in the bottom chamber, the paper leader must be passed through the two feeler rollers and drawn up on to the empty take-up spool. The feeler rollers will allow uninterrupted passage of the thin backing paper. Only when the increased thickness (at the point where film joins paper) goes through the rollers, does the automatic tripping mechanism allow the counter to go into action. The crank continues briefly and then stops, firmly — the film has reached the position for exposure No. 1. The pressure of the rollers is released immediately after the passage of the film's beginning so that the rest of the roll will slip through freely.

After the twelfth exposure, the counter mechanism automatically disengages and the crank turns freely, permitting the complete winding up of the fully exposed film.



II. THE ROLLEIFLEX IN OPERATION

The Eveready Case

deserves mention here since it is so often used with the camera.

The top and front of the case, when opened, hang down in front and keep out of the way by means of their own weight. The case may also be used with the Rolleikin 2 attachment merely by removing the leather insert to permit passage of the larger counter knob.

To Open: lift the top by grasping both sides at the rear and push forward (1).

To Close: pull the top over the camera and push down to engage the snaps. (Simultaneous folding of the focusing hood is also possible with this movement.) Always return focusing knob to infinity position since the extended front may otherwise interfere with closing the case.

To Remove Camera From Case: pull up the metal clips located at the top of the sides of the case (2). Lift the crank a little way from the case, spread the sides and lift the camera forward and out (3).

Putting the Camera in the Case: pull up the clips and spread the case apart; then slip the crank through the large opening from the inside and lower the camera backwards into the case. Push the clips down through the chrome plated strap holder slots.

For Cameras with Rolleikin 2: straighten out the five metal tabs of the leather insert on the inside of the case with a knife (4) and then push out the now superfluous disc.

The Lens Cap

is foldable. The upper part is attached in front of the viewing lens by bayonet mounting and the lower part through friction fit.

Removal of Lens Cap: lift the lower part by the tab at the lower edge and fold it against the upper part (5). Remove cap from the bayonet by turning it counter-clockwise $\frac{1}{4}$ of a turn (6).

Attaching Lens Cap: fit the folded cap into the bayonet of the viewing lens — hinge pointing to the right (focusing knob) — and fasten it with a $\frac{1}{4}$ turn clockwise. Fold down the lower part and snap into place.



1



2




3



4



5



6



Holding the Camera

Basic rule: camera hanging around the neck with taut strap and the camera held firmly by both hands. The right hand grasps the camera at the bottom, the index finger on the shutter release, the thumb supporting the uplifted crank (quick handling of the film transport: p. 34). The left hand does the focusing (1). In this position diaphragm and shutter controls may be operated comfortably with two fingers.

The **Carrying Strap** is adjusted to a comfortable length, so that the camera may be carried on the shoulder when not in use. In order that the shutter may be released with taut strap to avoid camera movement, loop the strap around the right hand, thus shortening it to achieve normal viewing distance (2). Further shortening of the strap when using the magnifier can easily be effected by making use of the left hand in the same way (3).



5

6

7

8

Caution: a wrong or uncomfortable "grip" may cause you to lift inadvertently the hanging top of the eveready case.

A leather neck strap is also available for working without the eveready case. To attach: slip both ends through the strap holder slots and fasten to the strap holder buttons. The strap holders can be swung backwards at an angle, so that the camera hangs comfortably in front of the body (4).

Waist-level or eye-level positions for the camera are considered normal for most pictures. The extremely flexible Rollei, however, readily permits exposures at or near floor level, overhead, shooting straight up or down, and occasionally, surprise snaps "around the corner". The illustrations (5—8) show a few possibilities for such pictures with the camera in different positions.



1



2



3

Focusing Hood

To Open: lift the rear edge of the focusing hood cover — Spring tension keeps it open (1).

To Close: pull back focusing hood (2).

Note: the focusing hood may be closed only with the magnifier in folded position.

The focusing hood may also be closed with the same hand movement that closes the eveready case (see page 12). The push-button in the middle of the divided stop bar on the rear of the focusing hood serves to hold the Rolleikin-ground-glass-screen mask.

Focusing Magnifier

To Raise: pull release lever in the open focusing hood upwards — the magnifier springs into position (3).

To Lower (before closing the focusing hood): push down magnifier flap until it snaps into position. Avoid touching the lens itself (4).

Use of the Magnifier: use the magnifier as close to the eye as possible.

The magnifier is interchangeable and may be replaced for the convenience of near or far sighted people. Strengths from minus three to plus three diopters are available.



4



5



6

Direct View Finder

To Open (after raising the magnifier): push the direct view finder flap inwards until it snaps into place (5).

To Close: depress magnifier flap slightly — the direct view finder panel immediately returns to normal position (6).

The subject is viewed at eye-level through the direct view finder and focusing may be checked by means of the second (also interchangeable) magnifier.

The two pin sockets and small knob on the front of

the hood permit attachment of the Rolleikin direct view finder mask.

Changing Magnifier (if eye-sight demands)

To Remove: pull back ring mount against retaining spring and lift out. To insert: put into position (back first), pull back against spring and snap down.

Rear Magnifier: to remove: push in slightly at top and lift out. To insert: slip magnifier (white dot uppermost) between retaining springs — push down until it snaps into place.



Focusing

Focus the Rolleiflex by turning the focusing knob, at the same time critically observing the sharpness of the ground glass screen image. The footage scale serves also to indicate the depth of field, a matter which need not concern you too much at first. The magnifier facilitates the most critical focusing. Important:

Focus so that the greatest degree of sharpness prevails at main subject distance.

The Diaphragm



The diaphragm controls the amount of light passing through the lens. It has a double effect:

Stopping down

increases the depth of field and
reduces the effective amount of light

Therefore the exposure must be increased correspondingly at smaller diaphragm openings. The following table gives the ratio of exposure at the different openings:

Diaphragm	3.5	4	5.6	8	11	16	22
Exposure	$\frac{3}{4}$	1	2	4	8	16	32

Notice that each succeeding smaller stop requires exactly double the exposure of the preceeding one. Only exception — the relation between f:3.5 and f:4. The diaphragm scale itself is easily seen, black figures, in the peep window above the viewing lens. The dot before f:22 indicates the position for f:16.

Setting the Diaphragm: with camera in operating position, turn the small knurled wheel on the left side, between the lenses.

Depth of Field

Most picture subjects require that acceptable sharpness extend somewhat before and behind the exact distance focused on. Landscapes, for instance, require considerable "depth of field". Two factors influence the extent of the sharp zone: distance actually focused on and diaphragm opening.

In contrast to close-up focusing the sharp zone is many times greater when the lens is focused on long distance:


1. The depth of field increases with the taking distance.

In any case, however, the sharp zone of the picture may be increased considerably by stopping down the diaphragm:

2. The depth of field increases when stopping down.

As a practical rule the second alternative is preferable and only in emergency cases should the taking distance be increased because of loss in image size.



The extent of the depth of field at any distance may be read off on the focusing knob.



Depth of Field Scale

On and next to the focusing knob two scales are visible: the movable focusing scale with figures indicating feet and the fixed depth of field scale with the diaphragm values. The diaphragm figures are arranged in pairs symmetrically on both sides of the central focusing point; the diaphragm openings $f:5.6$ and $f:11$ are represented by black sections below the scale.

The center of each footage figure indicates the correct setting for that distance.



In Practice

After focusing, the near and far limits of the depth of field may be read off directly below the pair of figures indicating the diaphragm opening chosen.

The section of the footage scale bracketed between the identical figures representing the diaphragm opening indicates the exact zone of sharp focus.

1. Example: focusing to 10 ft with diaphragm opening 8 gives a depth of field 8 ft to 12 ft. Focusing to 10 ft with diaphragm opening $f:16$ gives on the other hand a depth of field from 7 ft to 20 ft. (Stopping down improves the depth of field!)

Considerable stopping down necessitates greatly increased exposure time. To obtain depth of field with the largest possible diaphragm opening, a different method of focusing must be employed:

2. Example: the subject requires sharpness from 7 ft to 10 ft. (Other distances, if unknown, can be read directly off the scale after focusing separately to the limits required.) Procedure: the focusing knob is turned until both footage values are located opposite identical diaphragm openings, and in this way the most favorable diaphragm opening is obtained, in this case $f:8$.

Depth of Field Table (distances in feet)

Diaphragm		4	5.6	8	11	16	22	
Taking distance (in feet)	∞	141' $\frac{7}{8}$ " ∞	86' $1\frac{1}{2}$ " ∞	58' $6\frac{3}{4}$ " ∞	43' $1\frac{1}{2}$ " ∞	31' 4 " ∞	21' $5\frac{7}{8}$ " ∞	15' $7\frac{7}{8}$ " ∞
	60'	41' $11\frac{15}{16}$ " $100'$ 6 "	35' $5\frac{1}{4}$ " $198'$ 2 "	29' $6\frac{3}{8}$ " ∞	24' $11\frac{1}{4}$ " ∞	20' 8 " ∞	15' 9 " ∞	12' $5\frac{5}{8}$ " ∞
	30'	24' $8\frac{7}{8}$ " $38'$ $1\frac{7}{8}$ "	22' $3\frac{5}{8}$ " $45'$ $11\frac{1}{8}$ "	19' $8\frac{1}{4}$ " $60'$ $4\frac{3}{8}$ "	17' $8\frac{1}{4}$ " $99'$ $4\frac{3}{8}$ "	15' 5 " ∞	12' $5\frac{5}{8}$ " ∞	10' 2 " ∞
	20'	17' $6\frac{5}{8}$ " $23'$ $4\frac{5}{16}$ "	16' $7\frac{7}{8}$ " $25'$ 11 "	14' $9\frac{1}{8}$ " $30'$ $10\frac{1}{8}$ "	13' $9\frac{3}{8}$ " $41\frac{13}{16}$ "	12' $1\frac{5}{8}$ " $55'$ $5\frac{3}{8}$ "	10' 6 " $287'$ $\frac{7}{8}$ "	8' $10\frac{1}{4}$ " ∞
	15'	13' 7 " $16'$ $9\frac{15}{16}$ "	12' $9\frac{1}{2}$ " $18'$ $1\frac{1}{2}$ "	11' $9\frac{3}{4}$ " $20'$ $1\frac{1}{8}$ "	11' $1\frac{7}{8}$ " $22'$ $11\frac{5}{8}$ "	10' 2 " $28'$ $10\frac{1}{2}$ "	8' $10\frac{1}{4}$ " $46'$ $6\frac{1}{2}$ "	7' $6\frac{1}{2}$ " ∞
	12'	11' $1\frac{11}{16}$ " $13'$ $1\frac{1}{16}$ "	10' 6 " $14'$ $1\frac{1}{4}$ "	9' $10\frac{1}{8}$ " $15'$ $1\frac{1}{8}$ "	9' $6\frac{1}{8}$ " $16'$ $8\frac{3}{4}$ "	8' $6\frac{3}{8}$ " $18'$ $8\frac{3}{8}$ "	7' $6\frac{1}{2}$ " $27'$ $2\frac{3}{4}$ "	6' $10\frac{5}{8}$ " $51'$ $6\frac{1}{8}$ "
	10'	9' $4\frac{3}{16}$ " $10'$ $9\frac{1}{2}$ "	8' $10\frac{1}{4}$ " $11'$ $5\frac{3}{4}$ "	8' $6\frac{3}{8}$ " $12'$ $1\frac{5}{8}$ "	8' $2\frac{3}{8}$ " $13'$ $1\frac{1}{2}$ "	7' $6\frac{1}{2}$ " $14'$ $9\frac{1}{8}$ "	6' $10\frac{5}{8}$ " $18'$ $8\frac{3}{8}$ "	6' $1\frac{1}{4}$ " $27'$ $6\frac{3}{4}$ "
	8'	7' $6\frac{15}{16}$ " $8'$ $5\frac{15}{16}$ "	7' $2\frac{5}{8}$ " $8'$ $10\frac{1}{4}$ "	7' $1\frac{1}{4}$ " $9'$ $2\frac{1}{4}$ "	6' $9\frac{1}{8}$ " $9'$ $10\frac{1}{8}$ "	6' $4\frac{3}{8}$ " $10'$ $9\frac{7}{8}$ "	5' $10\frac{1}{16}$ " $12'$ $9\frac{1}{2}$ "	5' $3\frac{3}{8}$ " $16'$ $4\frac{1}{8}$ "
	7'	6' $8\frac{5}{16}$ " $7'$ $4\frac{9}{16}$ "	6' $5\frac{9}{16}$ " $7'$ $6\frac{1}{2}$ "	6' $3\frac{3}{16}$ " $7'$ $10\frac{1}{2}$ "	6' $2\frac{7}{16}$ " $8'$ $2\frac{7}{16}$ "	5' $8\frac{1}{8}$ " $8'$ $10\frac{5}{16}$ "	5' $3\frac{3}{8}$ " $10'$ $6\frac{1}{8}$ "	4' $9\frac{7}{8}$ " $12'$ $5\frac{5}{8}$ "
	6'	5' $8\frac{7}{8}$ " $6'$ $3\frac{3}{16}$ "	5' $7\frac{5}{16}$ " $6'$ $5\frac{9}{16}$ "	5' $5\frac{3}{8}$ " $6'$ $8\frac{5}{16}$ "	5' $3\frac{3}{8}$ " $6'$ $11\frac{7}{16}$ "	5' $1\frac{1}{4}$ " $7'$ 5 "	4' $8\frac{5}{16}$ " $8'$ $4\frac{4}{8}$ "	4' 4 " $9'$ $8\frac{1}{2}$ "
	5'	4' $9\frac{7}{8}$ " $5'$ $2\frac{3}{16}$ "	4' $8\frac{11}{16}$ " $5'$ $3\frac{13}{16}$ "	4' $7\frac{1}{8}$ " $5'$ $5\frac{3}{4}$ "	4' $5\frac{15}{16}$ " $5'$ $7\frac{3}{4}$ "	4' $3\frac{9}{16}$ " $5'$ $11\frac{1}{4}$ "	4' $\frac{15}{16}$ " $6'$ 6 "	3' $9\frac{5}{16}$ " $7'$ $4\frac{3}{16}$ "
	4'	3' $10\frac{5}{8}$ " $4'$ $1\frac{3}{8}$ "	3' $9\frac{11}{16}$ " $4'$ $2\frac{3}{8}$ "	3' $8\frac{7}{8}$ " $4'$ $3\frac{9}{16}$ "	3' $7\frac{11}{16}$ " $4'$ $4\frac{3}{4}$ "	3' $6\frac{1}{2}$ " $4'$ $7\frac{1}{8}$ "	3' $4\frac{9}{16}$ " $4'$ $11\frac{1}{16}$ "	3' $2\frac{3}{16}$ " $5'$ $4\frac{9}{16}$ "
	3,5'	3' $4\frac{15}{16}$ " $3'$ $7\frac{1}{8}$ "	3' $4\frac{3}{16}$ " $3'$ $7\frac{11}{16}$ "	3' $3\frac{3}{4}$ " $3'$ $8\frac{1}{2}$ "	3' 3 " $3'$ $9\frac{11}{16}$ "	3' $1\frac{13}{16}$ " $3'$ $11\frac{1}{4}$ "	3' $1\frac{1}{4}$ " $4'$ 2 "	2' $10\frac{1}{4}$ " $4'$ $6\frac{5}{16}$ "
	3'	2' $11\frac{1}{4}$ " $3'$ $1\frac{3}{8}$ "	2' $10\frac{5}{8}$ " $3'$ $1\frac{3}{8}$ "	2' $10\frac{1}{4}$ " $3'$ $1\frac{3}{8}$ "	2' $9\frac{7}{16}$ " $3'$ $2\frac{3}{16}$ "	2' $8\frac{11}{16}$ " $3'$ $3\frac{3}{4}$ "	2' $7\frac{1}{2}$ " $3'$ $5\frac{5}{16}$ "	2' $6\frac{5}{16}$ " $3'$ $8\frac{1}{2}$ "
	2 $\frac{2}{3}$ '	2' $7\frac{5}{16}$ " $2'$ $8\frac{1}{2}$ "	2' $7\frac{1}{8}$ " $2'$ $9\frac{1}{16}$ "	2' $6\frac{11}{16}$ " $2'$ $9\frac{7}{16}$ "	2' $5\frac{15}{16}$ " $2'$ $9\frac{7}{8}$ "	2' $5\frac{1}{2}$ " $2'$ $11\frac{1}{16}$ "	2' $4\frac{3}{8}$ " $3'$ $\frac{5}{8}$ "	2' $2\frac{3}{16}$ " $3'$ $2\frac{3}{16}$ "
Diaphragm	3.5	5.6	8	11	16	22		

Since the sharp zone in the picture does not end abruptly, but gradually changes to something less sharp, it is generally sufficient to read the depth of field in round figures. With this in mind the scale on the focusing knob has been calibrated for quick and practical use.

If exact figures are desired, these may be found in the table on page 21.

The Depth of Field Table

For normal use the upper of the double row of diaphragm figures is used as in the case when an enlargement is to be made later from the entire $2\frac{1}{4} \times 2\frac{1}{4}$ negative. (These diaphragm openings are based on a circle of confusion of $1/1400$ of the focal length.)

On the other hand if enlargements are to be made from a small portion of the negative (or Rolleikin negatives) it is advisable to go by the lower row of diaphragm openings (circle of confusion = $f/2000$).

Explanation: the degree of sharpness required from a negative is exclusively dependent on the magnification of the prospective enlargement and its subsequent viewing distance.

In order to obtain a correct perspective impression at 10" (a comfortable viewing distance) a whole Rollei negative would have to be enlarged $3.3 \times$ to $7\frac{1}{2} \times 7\frac{1}{2}$ ". Enlargements of this size, viewed at 10", determine the basis for the minimum acceptable sharpness. With this in mind the size of the circle of confusion is computed and the limits of the depth of field ascertained. Negatives made in this way will permit enlargements also to larger sizes, while still retaining the same impression of sharpness. This is because the viewing distance is always correspondingly increased.

With enlargements from portions of Rollei negatives or from Rolleikin negatives, the requirements with regard to sharpness are more critical. In this case depth of field is calculated using a smaller circle of confusion. In practical use the required depth is obtained through the use of a smaller diaphragm opening.

The effectiveness of the scale on the camera itself may be extended in the same manner merely by using the next smaller diaphragm opening than the one indicated for the desired zone.

If enlargements of very great size are to be made use a diaphragm opening two stops smaller than the one indicated.

Speed of Moving Subjects and Shutter Speeds

		Miles per hour approximately																	
		3 mph		6 mph		12 mph		30 mph		60 mph		120 mph							
Example:		Pedestrians		Runners Moving air		Bicycles Windy		Light Athletics Stormy Surf		Automobiles Railway Trains Racing		Motor Racing							
Distance (yards)	40		1/25	1/50	1/25	1/50	1/100	1/50	1/100	1/250	1/100	1/250	1/500	1/250	1/500		1/500	50	Distance (yards)
	15	1/25	1/50	1/100	1/50	1/100	1/250	1/100	1/250	1/500	1/250	1/500		1/500				25	
	8	1/50	1/100	1/250	1/100	1/250	1/500	1/250	1/500		1/500							12	
	4	1/100	1/250	1/500	1/250	1/500		1/500										6	

Moving Objects require short shutter speeds in order to be reproduced sharply. For this purpose the table contains accurately computed minimum values, depending on the factors: speed, distance and direction. Taking distance: the yard-column on the left stands for sufficient sharpness (f/1400), the yard-column on the right for increased sharpness (f/2000). In spite of these normally correct figures,

it is often possible in actual photography to use longer shutter speeds. This is because the eye interprets slight unsharpness as giving an added impression of speed.

A long arrow = direction of movement.

Short arrow = taking direction (→ up to 10°, ↗ up to 30° and ↑ up to 90° to the direction of movement).

Self-Timer

If the photographer himself wants to appear in the picture, the self-timer is employed instead of the shutter release button. It is cocked automatically by crank action (and is always ready for use). With the exception of B all shutter speeds from 1 to 1/500th sec. may be used. The action of the self-timer allows the photographer approximately 10 seconds before the shutter opens for the previously selected exposure time.


If the shutter has just been released by hand it is perhaps needless to say that the crank must be wound before either a self-timer or any other kind of picture can be taken.

Operation of the Self-Timer: push the self-timer release button in the direction of the arrow.

The shutter and self-timer may be left cocked even when the camera is laid away for short periods of time without weakening the power of the springs. A good habit to develop, however, is to leave the cocking of the shutter until shortly before the exposure, so that 1/500th sec. may be used, if required.

The Exposure

The correct exposure is dependent upon existing illumination (more exactly: subject brightness) and results from the selection of the proper diaphragm opening and shutter speed. Consequently the following relationship exists:



With the Rolleiflex, various settings of diaphragm openings and speeds may be combined as required for normal picture-taking. Only under unfavorable shooting conditions are these possibilities limited, so that a compromise solution is sometimes necessary. Nevertheless the following must be kept in mind: under-exposure results in hopelessly lost shadow detail, whereas over-exposure may be compensated for to a great extent by proper processing.

A golden rule for safe exposure:

Always expose for the **shadows**, rather a bit **more** than too little!

The Exposure Table

The table on the back of the camera is based on the speeds of the two most commonly used types of film: the upper scale is used with films rated at 100 ASA (21/10° DIN), and the lower scale is used with film rated at 50 ASA (18/10° DIN). Conversion of the table for use with other film speeds is possible if it is remembered that half the ASA rating (or minus 3/10° DIN) means that double the exposure is required.

For the two months immediately bracketing the summer months or if the sun is lower in the sky or if the sky is overcast, double the indicated exposure. If more than one of these conditions prevail, double the exposure for each factor.


Exposure in the wintertime around noon: with snow — use the normal values of the table, without snow — multiply exposure by 4.

The table, although not always exact, has nevertheless proved itself so good that serious exposure errors are generally avoided. In difficult cases or for greatest accuracy, it is advisable to use a photo-electric exposure meter.

Auxiliary Focusing Knob with Film Indicator

A really practical aid towards obtaining correct exposures, the auxiliary focusing knob (p. 53) contains two adjustable discs, variable according to film type and speed. Thus it is always possible to know what kind of material was last loaded in the camera. Furthermore, the larger, easier-to-grip shape and large footage scale facilitates accurate focusing under specially difficult working conditions, such as when using gloves in cold weather.






1



2



3

III. LOADING AND FILM TRANSPORT

The Rolleiflex is loaded with $2\frac{1}{4} \times 3\frac{1}{2}$ roll-film 120 or B II 8 (620 not usable) and delivers 12 exposures $2\frac{1}{4} \times 2\frac{1}{4}$. (See page 29.)

The loading of the camera is confined to a few simple operations: open the back — insert the full film spool — thread the film — close the back. From now on the film transport follows automatically through crank action.

Back

To Open: swing aside the back locking lever at the bottom of the camera (1), lift the clip (2), open back (3), using the clip as a handle.


To Close: with the flat of the hand push the back closed, fold down the clip and return locking lever to full forward position.



4



5



6

The back is generally removed only when replaced by the plate adapter.

To Remove: push both back hinge clips upwards (4) and open back fully (5). Press back sideways against the hinge and at the same time remove it from the free end (6).

To Attach: insert the detached back's hinge pins first in one and then in the other hinge, press the hinges against the camera and secure them with the clips.

Protect the open camera against prevailing dust and dirt and clean it occasionally with a soft camel's hair brush!

Never change film in direct sunlight, utilize at least your own body's shadow!


Note: for the Rolleiflex the following adapter accessories are also available: Rolleikin 2 Attachment for 36 exposures 24×36 mm or 35 mm film, Plate Back Adapter for separate exposures $2\frac{1}{4} \times 2\frac{1}{4}$ " on plates or cut films $2\frac{1}{2} \times 3\frac{1}{2}$ ".



1



2



3

Film Pressure Plate Must be Positioned Correctly!


When roll film is employed, the inscription $2\frac{1}{4} \times 2\frac{1}{4}$ " must be visible below the film pressure plate. When changing from 120 roll film to 35 mm film, or the reverse, an adjustment must be made according to the film type being used.

To adjust the film pressure plate (1): Press the plate against the back and push it up or down until it stops. When released it must spring forward completely into the normal plane!

Inserting the Film Spool

In the factory-new camera the empty spool (take-up spool) is already in position. After removal of the exposed film the just emptied spool becomes a take-up spool, and must be transferred to the upper spool-chamber. The end with the slot goes to the right engaging the winding key of the film transport mechanism (2).


Both spools are held on the left hand side by spool knobs. The bearing pins are withdrawn when changing spools by pulling out the knobs,



4



5



6

The pulled out upper knob (take-up spool) may be held in that position by turning it slightly; turning it a little more permits it to snap back by itself.


To Insert the Empty Spool: first fit the spool over the winding key on the right (crank side) and pull out the guide knob (3). Push the spool down on the left applying slight pressure, so that the knob may snap back into place fully (4). It is then necessary to turn the crank until the long slot in the empty spool comes uppermost (5).

Note: when using an adapter the empty spool must be removed from the camera. However, it must be handily retained especially on trips, since otherwise a new roll-film cannot be loaded into the camera.

To Insert a Full Film Spool: in the same way as applies to the take-up spool (6). The pointed end of the backing paper must point in the direction of the take-up spool chamber, so that the colored side of the backing paper remains on the outside.



1



2



3

Threading the Film (Paper Leader)

After inserting the new film-spool tear the tape seal open and remove it.

1. Thread the beginning of the backing paper **through the rollers** of the film feeler mechanism (important!) and draw it up to the take-up-spool, colored side outwards (1).

2. Push the paper leader through the long slot of the take-up-spool as far as it goes (2).


3. Tighten the backing paper by one spool turn (= approximately $\frac{3}{4}$ crank turn), making sure that the paper is wound up properly on the take-up spool (3). Close back (with the film pressure plate adjusted according to instructions!).

Film Transport

The correct positioning of the film according to the first and following numbers of the exposure counter is accomplished exclusively by the crank. The correct operation of this is governed by stops:



4



5



6

Swing out crank (4),
turn it until it stops with one continuous
swing (5) and then back again until the next
stop (6)!

It is now locked, until the automatically cocked shutter
is released. The simple rule then reads:

If the crank can be turned, it must be
turned — once in each direction until it stops,
until it locks!

When advancing the film to exposure No. 1 some 4
to 5 complete crank turns are required. During
the last turn a slight resistance of the mechanism
must be overcome as the counter moves from 0 to 1.
If it should happen that the crank reaches starting
position when it stops, reverse direction one full
turn, so that it locks!


During continued film transport the amount of crank
travel decreases gradually to about a half turn.



1



2



3

When making exposures in rapid succession it is unnecessary to fold down the crank each time. It remains locked in its starting position, ready for the next film advance, with a slight pressure of the thumb keeping it against its stop.

If longer intervals obtain between exposures the question could arise: has the film already been advanced and the shutter cocked? The crank gives the answer immediately:

Only if locked is it "ready to shoot"!

To Remove the Film

After the 12th and last exposure four complete crank turns are enough to wind off the rest of the backing paper (1).

To Remove: open the back in the shade, pull out upper spool knob and remove the film from the same side (2). Fold under a good portion of the backing paper (for easier opening when developing) and seal (3). Put the exposed film back into the light-proof protective cover of the original package!

IV. FLASHLIGHT-TECHNIQUE

In modern flashlight-technique the camera shutter takes over the task of firing the bulb electrically at the right moment. In this way instantaneous flash exposures are possible with a hand-held camera.

The Synchro-Compur shutter in the Rolleiflex is, for this purpose, equipped with electrical contacts. The contact may be adjusted to the required delay of the flash lamps by means of the Synchro-lever:

the **X-contact** presents the simplest type of contact. It is required for zero-delay electronic flash units (without relay) and a few flash lamps.

The **M-contact** means full synchronization. It works with most flash lamps and the electrically fired flash powder (capsule flash). The most important advantage of the M-contact: with certain flash lamps it may be employed at the shorter shutter speeds even including 1/500th sec. Due to the full synchronization the shutter is always open when the flash emitted by the lamp reaches its peak intensity.




Thus all types of instantaneous flash exposures are possible with the Rolleiflex.

The selection of flash lamp-type depends on the light output required by the subject. Many makes are available in three groups (normal, medium and high light output). The selection is dependent on the taking conditions, especially as to whether a room of shallow or great depth is to be illuminated.

The flash attachment is connected to the camera by means of the flash cable, plugging into the special socket provided therefore. Specific information regarding exposures are generally provided in the instructions for the individual types.

Since the development of flash light sources still is in the experimental stage, numerous makes of varying efficiency are available commercially. The best known are compared in the table on page 36. Therein will also be found the required contact information and the permissible shutter speeds.

Flash contact and permissible shutter speeds

FLASH LIGHT SOURCE		Type	Contact	Shutter Speeds:	
Make				Fastest	Slowest Recommended
I. Electronic Flash		Without Relay (1/500)	X	1/500	1/250 1
General Electric	SM	(1/200)			
	Westinghouse				
Sylvania	SF	(1/200)	X	1/100	1/100 1
Osram	FO	(1/100)	X	1/50	1/50 1
	F1, F2	(1/50)			
	XP, XO	(1/200)	X	1/25	1/25 1
Osram	S2		M	1/500	1/25 1
	S0, S1				
Philips (Mazda)	PF 3N, PF 14, PF 25, PF 56				
General Electric	No. 5, 11, 22		M	1/500	1/50 1
Westinghouse	Press 25, 40, No. 0				
	No. 2		M	1/100	1/50 1
Philips (Mazda)	PF 110				
General Electric	No. 50		M		
Westinghouse				1/50	1/25 1
Sylvania	No. 3				
General Electric	No. 6, 31		M	1/250	1/25 1
Westinghouse					
Sylvania	FP 26, No. 2A				
III. Capsule Flash		Average	M	1/100	1/25 1

II. Flash Lamps

Explanation of the Table

The **"Contact"** column indicates the correct setting of the M-X lever for each lamp type.

The **"Shutter Speeds"** column shows the permissible speed range. In all cases, one speed is recommended as "standard":

this standard recommended speed is the fastest usable one which still manages to include practically the entire light output of the lamp. When maximum illumination is wanted or if the use of a small diaphragm opening (for greater depth of field) is desired, it is necessary to apply the following general rule:

Use the standard recommended speed together with the correct setting of the M-X lever for the lamp in use.

The fastest shutter speed is the shortest one that can be used with the particular lamp and must not be further reduced. This is the speed which must always be used with lively action or sport subjects.

The slowest speed in all cases is always 1 sec. Time exposures of varying duration can also be used if it is desired to make use of existing light in addition to the flash. In such cases the total amount of light from both sources must be considered in choosing the diaphragm opening.

Shutter Speed and Effective Speed are not in every case identical when using flash. The effective speed is therefore indicated in the table by means of colored ink:

with **X-contact** the duration of the flash itself (figure shown in parenthesis) is the actual exposure time or effective speed, since this interval is only a fraction of even the fastest permissible shutter speed. Thus the identical diaphragm opening is used for any of the indicated speeds.

With **M-contact** the fastest speeds utilize only part of the flash so that the diaphragm must be opened accordingly. Entire flash duration becomes available only at or below the "recommended" speed.

The illustration should make the utilization of the available flash light still more obvious: the white symbols represent the flash, and their size, the utilized light at the shutter speed employed.

How the Flash Contacts Work

The information given thus far is entirely sufficient for normal purposes and is adequately supplemented by the exposure tables usually furnished by the various flash lamp manufacturers.

The photographer who is familiar with and habitually makes use of flash lamp graphs should know something about the method of operation of both flash contacts.

X-Contact (zero-delay): contact is made shortly before the shutter blades reach full opening. Application: for lamps with short firing time (up to 5 milliseconds) and short flash duration.

M-Contact (full synchronization): contact is made approximately 16.5 milliseconds before the shutter blades are fully opened. Application: for flash lamps with long firing time (average firing delay 16.5 milliseconds) and long light duration.

For safety reasons one pole of the contact is grounded to the camera body (isolation-test: 700 volts). All commercially available flash guns and electronic flash units may be used. Current-carrying capacity of the contact when several flash lamps are connected simultaneously: 10 ampères at 24 volts for a period up to a maximum of 1/10th sec.

Tips on Flashlight - Photography

1. Use fresh batteries. Condenser or capacitor flash-guns are more consistent since lamp ignition is somewhat less dependent on battery power.
2. Be sure that the contacts of the battery and lamp sockets are clean. Handle flash cable with care, avoid kinking, otherwise there will be danger of short-circuit and premature flash ignition. — Note: the contact must not be connected to house current!
3. Blue flash lamps, like electronic flash, simulate daylight and are intended for use with daylight color film.
4. The power of flash illumination decreases according to the square of the distance: i. e., an object six feet away receives only half the light as an object at three feet. Distance from flash to subject must therefore be carefully considered in selecting diaphragm opening. Lamp manufacturers supply easy to use guide numbers which are divided by the distance in feet to obtain the required diaphragm opening.
5. Flash as main light source: do not take weak room illumination into account, expose strictly according to flash output.
6. Flash as fill-in light: useful in brightening shadows whether due to insufficient illumination or to the

fact that the picture is being taken "against-the-light", in full sunlight. The fill-in light must be kept at a lower intensity level than the main source of illumination, otherwise the strong flash will give an unnatural effect, not at all like daylight. Too strong a flash might even cause an apparent underexposure of the sky or the area not reached by the light. Electronic flash units are particularly well suited for use as fill-in lights when shooting color sports pictures. Use smaller lamps or keep them at greater distance.

7. Reducing the blinding effect of flash: the flash from regular flash lamps may be made "invisible" by dip coloring the bulb. Color solution No. 1 (200 cc warm water + 10 cc glycerin + 4 grams methylviolet) is used for panchromatic films. Open diaphragm 2 stops. Tone values are not changed in the picture. Additional dipping in color solution No. 2 (200 cc water + 10 cc glycerin + 4 grams tartrazin) will do for infra-red film. Open diaphragm 3 stops.

8. Developing: normal development of electronic flash pictures tends to produce insufficient contrast due to the very short time that the light is allowed to act on the film. The remedy is to develop longer or to use special "hard" developers.



1:5.6 • 1/250

Electronic flash





1:11 • 1/10 filter light green



V. TIPS ON PICTURE-TAKING

Landscapes

Focusing Rule: distant views with foreground. Focus on part of subject nearest to camera and then set focusing knob to twice the distance — use diaphragm setting indicated opposite ∞ . Example: close point is 15 ft, set focus to 30 ft, diaphragm opening indicated opposite is f:11. Depth of field is from 15 ft to ∞ .

Filters: important for separating tones which would otherwise be similarly rendered by the black and white film or for influencing the mood of the picture.

1. Blue Sky with Clouds: yellow filters darken blue skies and thus improve the reproduction of clouds. The deeper the color of the filter, the stronger and more dramatic the effect. Blue snow shadows are also rendered truer to tone. The green filter tones down the sky, brightens foliage and darkens the occasionally too lightly rendered reds (with pan film) such as sun-tanned flesh and red tile roofs. The graduated filter, used with the lens hood, can be set to filter the sky only. The Rolleipol filter subdues or eliminates polarized light only and can be used to darken the sky with both black and white- and color films.

2. Haze and Mist: the blue filter, useful for pictorial effects, increases hazy effect. The orange or red cut through and improve the clarity of distant views. The blue filter reduces contrast, the red or orange increase brilliance. Maximum penetration of light haze is obtained with infra-red film and infra-red filter (700 m μ). Barely visible mountain chains are reproduced clearly. An odd effect with this combination is that green leaves are rendered almost white. Filters are of no use at all in really bad weather when there is a good deal of moisture in the air.


3. Sea, Beach, Mountains: strong ultra-violet rays must be absorbed through use of UV filter. Results will otherwise be dull. The H 1 filter serves the same purpose for daylight-color film. Reduction of the bluish cast is quite marked.

Picture Composition Rules: distant views are generally better if foreground contains (for added depth impression) trees, people, animals, etc. Foliage is often used as a frame for the distant view. Focus should be sufficiently sharp in the foreground. Strong effects are created when deep shadows in the foreground are set against the lighter distance. Side lighting or even back lighting give the most impressive pictures.



1:5.6 • 1/25

Filter light yellow





1:5.6 · 1/100 · filter medium yellow



Portraits

Large heads: do not work closer than 40 inches to avoid possible perspective distortion. If necessary, enlarge from a smaller section or use Rolleikin. Focus on the eyes. Use quiet, neutral colored backgrounds and do not stop down too much ($f:5.6$) so as to keep backgrounds from intruding. If possible, move subject away from background. Out of doors, try using sky as only background. Open air portraits are best taken early or late in day when light is softer and not too blinding. Favor soft light, avoid deep shadows. In emergencies use reflectors or fill-in flash. Simple, proven artificial light procedure: lamp No.1 next to camera somewhat above head level, lamp No.2 on the side to lighten shadow, approximately $1/25$ th sec. For special effects, lamp No.3 as overhead or back-light. Important: use lens hood and focusing extension hood for reducing extraneous light. Pan film, no filter. Moisten lips (highlights!). To reduce sharpness and add "glamor": Rollei soft diffusion disc 0 or 1 (stronger) over lens. Use larger diaphragm openings and backlight for sunny effects.

Children

Never use force, watch for interesting effects and expressions carefully. A clever assistant to divert children's attention from camera is often a valuable ally. Try close-up shots of children's expressions as they listen to favorite or exciting stories. Laughter, astonishment, pity and even an occasional yawn provide wonderful material for good shots or picture series. For close-up shots use same technique as for portraits. For children in motion, use snapshot technique outdoors and flash indoors. Low view points and close-up effects are best.

Animals

Patience, quietness and familiarity with the animal and its peculiarities are great assets. Close up pictures are most rewarding; use portrait technique. Make use of natural light effects such as back-lighting. Action pictures: use snapshot or sport technique (with flash, if needed). Rolleinarars are often helpful with small animals. Zoo: animal portraits — avoid bars or netting. Hint: netting often becomes invisible when lens nearly touches wire. — Fish in aquarium: use side and overhead lighting in otherwise darkened room. A good trick is to limit movement of fish within sharp zone by means of vertical glass plate in tank.



1:4 • 1/100 • Rolleisoft 1

Filter light green





1:5.6 1/250

Snapshots

Unexpected picture opportunities or rapidly changing subject distance make a simplified technique, based on depth of field zones, highly desirable. The following three settings have been found very effective:

1/100 sec.

Diaphragm opening f : 8

Short distances
approx.
9 to 18 ft

Medium distances
approx.
13 to 33 ft

Long distances
approx.
18 to 100 ft

12 ft

20 ft

30 ft

Shutter speeds and diaphragm openings do not often need changing in sunlight. Those suggested cover most contingencies. Thus instead of wasting time focusing when in a hurry, use one of the above settings. This snapshot technique is especially useful with the direct view finder. Variation of the values (see table page 21) makes this technique available for other depth of field zones. Example: diaphragm opening f : 11, focus at 30 ft, depth of field extends from 15 ft to ∞ for snapshots of scenes. Chief uses for this technique: groups in motion, sport scenes, playing children, reportage, sports.

Sports

Sports pictures are generally most effective when the original rapid motion has been sufficiently "arrested" and the subject remains well defined. The fastest shutter speeds are essential, together with careful focusing. Sometimes prefocusing on the spot where the action is to take place is possible. Do not overlook the possibilities of training sessions since greater cooperation can often be had at such times. Snapshot technique is valuable for turf and ice shots and for any case when it would be difficult to guess exactly where to focus. Watch your shutter speeds and viewing angle. Shooting at right angle to the direction of the action requires a much faster speed than when the action is going in other directions (see table page 23). If the action is very fast or takes place close to the camera it is best to pan or follow with the camera. This results in a sharply rendered main object against a blurred background, thus increasing the impression of speed. There is often a fine moment for shooting when the action reaches a peak and stops momentarily, such as when a pole-vaulter "hits the top" before starting to come down again. With insufficient light or indoors use synchro-flash and 1/500th sec. The extremely short duration of electronic flash is extremely desirable in some instances. Filters: if needed, use the Sport filter, which requires minimum extra exposure. Use the direct view finder; do not overlook the advantages of the Rolleikin with its telephoto effect, maximum use of film area and greater film capacity.



1:3.5 1/500



Theatre and Music-Hall

At longer distances only a section of the film is generally used hence this is a good field for using the Rolleikin. Do not depend on footlights but concentrate on spot-lighted performers or features. Exposures of $1/25$ th sec. are generally adequate under the strong lights with fast pan film. Color-dipped flash lamps (see page 39) permit flash exposures without disturbing spectators. After pre-setting focus you can use direct view finder most comfortably.


Night

Include direct light sources as symbols of the night in the picture. Only very strong, close lamps must be hidden behind natural foreground objects (building, tree, persons) otherwise over-exposure will result. Make use of effects: reflections in wet streets, light deflected by snow, early twilight with traces of brightness in the sky. Use fast pan-film only. For Time exposure: cover up lens when auto headlights cross the picture area, to avoid streaks. Use flash for snapshots at night, not for night shots.




Copying

Smaller originals are best copied with Rolleinar. See table page 55 for reproduction sizes. The camera should be set on a rigid, vibration free stand with the original parallel to the film plane. Use a small stop; $f:11$ recommended. Light evenly from both sides but avoid reflections. Glossy surfaces give less trouble if Rolleipol is used. Colored originals may require filter for better tone separation. Use contrasty ortho film (or even positive film with Rolleikin) for black and white originals. Spots on originals can be minimized by using a filter similar in color to spot with pan film. The Rolleikin is especially valuable for series or archive work. Single reproductions are economically taken with the plate back adapter. Reproductions from books are readable with ordinary magnifier directly from $2\frac{1}{4} \times 2\frac{1}{4}$ contact prints. Small objects (small machine parts, assembly pieces) may be handled similarly to copying. A spotlight can often be an additional aid in this case. Shadow-less lighting effects are facilitated by placing object on a suspended glass plate. Reflections from fine glassware or other highly reflective objects can be reduced to a minimum if the object is photographed by reflected light such as can be had inside an illuminated, white painted box.



1:8 • flash • Rolleinar 2





Rolleipol



Shiny Surfaces

Eye-glasses, pictures, water surfaces, window glass and other brilliant reflecting surfaces often give disturbing reflections, not always avoidable by changing angle or illumination. A simple remedy in many cases is to use the polarizing filter Rolleipol. Reflected light is often polarized in one direction and this can be absorbed or reduced by proper orientation of the Rolleipol. This is done by merely turning it for best effect. It may sometimes be necessary to change camera position to obtain best angle. In artificial light a second pola-filter over the light gives full control at any angle. When the reflections are removed objects seen through the shiny glass or water surfaces become clearly evident. Torsion or strain tests of various materials are also possible with the help of the Rolleipol. Reflections from certain metal surfaces when the Rolleipol has little or no effect are best handled by photographing in diffused light or changing direction of illumination. Small, shiny metal parts can be held over burning magnesium to provide a white coat or greased and rubbed with graphite.

Plants

Flowers, blooms and grass are most effective in close-ups taken against the light. Use Rolleinar's with fill-in light or reflectors. Parallax compensation can be had with Rolleipar (see page 9). Stop down for needed depth of field and shoot in bright light with no wind. A semi-circular shaped cellophane shield is an effective guard against the ground breezes that destroy definition. Use filters to differentiate between equally bright colors. Keep in mind that a filter renders its own or similar colors lighter, whereas its complimentary color comes out darker.

Color Photography

Color films have little exposure latitude, so avoid strong light contrasts and use exposure meter. In doubtful cases make three exposures, varying diaphragm opening one half stop each side of what is considered normal. Correct color reproduction is possible only with correct matching of proper film types with illumination. Use compensating filters when needed according to manufacturer's instructions. Select subjects with pleasing large color patches, not just an accumulation of loud colors. Overcast sky often renders pleasing pastel effect.



Rolleinar 2





Panorama-Pictures

Special landscape pictures of distant views, which include a large portion of the horizon, are made possible with the panorama head when used in conjunction with a tripod. Either a few succeeding exposures can be made for normal panorama purposes or up to ten can be taken in order to cover the complete (360°) horizon. The separate pictures can be joined so that nothing is missing. When

exposing: watch for any change in illumination and take pictures quickly if clouds are moving briskly.

Stereo-Pictures

The stereo attachment, used with a tripod, makes possible the taking of stereo pictures of stationary objects. Two separate exposures are made. The pair of pictures, when viewed in a stereoscope or by



means of a stereo projector, assume the three-dimensional effect of natural vision (see illustration page 51). Although limited to non-moving objects the stereo field open to the Rolleï user is a wide one. Use a rigid tripod and stop down for ample sharpness throughout picture. Identical focus and exposure are also necessary for both exposures. Close-up pictures enhance stereo effect. Extreme close-ups with Rolleinars are also possible and in this case the normal

distance between taking positions may be lessened. Chief application: landscapes, architecture, interiors. Professional, press and scientific photographers will find it possible to make stereo pictures of machine installations, technical and structural details, manufacturing processes, collector's items, pieces of art, etc. Advantage of the stereo picture: natural and clearly apparent space proportions and depth relations; useful also for measuring purposes.

Pictures Through the Microscope

When a microscope is focused by someone with normal eye-sight the eye sees the image as if it were at infinity. Consequently, the Rollei, also focused at infinity, can simply take the place of the eye over the microscope in order to record the image on film.

Microscope and camera should be mounted on firm stands, without mechanical connections. Place the camera so that taking lens, focused at ∞ , is brought as close as possible to the ocular. Check optical axis carefully; film plane should be parallel to surface being photographed. For full coverage of $2\frac{1}{4} \times 2\frac{1}{4}$ use wide angle ocular, however sufficient coverage for Rolleikin negative is to be had in any case. Framing through view finder is unnecessary. Do not stop down since this has no effect on exposure. Factors affecting exposure are illumination and transmission of the objective, to be ascertained through tests. Apochromatic micro-lenses are best, particularly with color film. In shooting black and white with these lenses, use ortho material and green filter. Generally interesting are micro-pictures of crystallized chemicals through Rolleipol filter in conjunction with another pola-filter over microscope condenser.

Care of the Rolleiflex

A precision camera demands care in handling. Protect it against moisture, dust, sand, strong sunshine, hard blows or falls. First safeguard: the eveready case. Second safeguard (when not in use while traveling): a rubber bag to guard against water, sand or snow. Carry camera around neck to minimize transportation shocks. Keep all parts clear and clean lenses with a soft camel's hair brush or doeskin. Although the mechanism is not unduly sensitive to cold, some condensation may form on the lenses when the camera is brought in to a warm room from outside in cold weather. Do not wipe off — let moisture evaporate. In the tropics arrange to keep the camera, when not in use, in an air-tight container.

In Case of Damage to the Rolleiflex

The task of repairing major or minor damage is the special province of the expertly trained mechanic. Franke & Heidecke maintain their own special workshop in which all repairs are done with precision at nominal prices. Abroad, apply to photo dealers and factory representatives for full information.

The Practical Accessories for the Rolleiflex

Code:		Code:	
Berau	Ever-Ready Case for Rolleiflex-Automat	Lekoe	Leather Case containing: 2 Sets of Rolleinar Lenses, 2 Rolleipar Lenses and your choice of 5 Filters
Baobe	Lens-Hood		
Baspo	Rollei Sport Filter	Kolee	Leather Case (without contents)
Baihe	Rollei Yellow Filter, light	Foapt	Plate Adapter
Baimi	Rollei Yellow Filter, medium	Fosli	Slide
Balin	Rollei Green Filter, light	Focas	Leather Case for 2 Slides
Baeen	Rollei Green Filter	Fofoc	Focusing Screen Slide
Basky	Rollei UV Filter	Fopla	Cut-Film Sheath
Baora	Rollei Orange Filter	Focom	Complete Plate Adapter Equipment comprising: 1 Plate Adapter, 3 Slides, 1 Focusing Screen Slide, 1 Leather Case for 2 Slides
Baubi	Rollei Red Filter, light		
Babla	Rollei Blue Filter, light	Rolki	Rolleikin 2
Bahaz	Rollei H 1 Filter (UV Filter for Color Photography)	Foead	Panorama Head
Bafir	Rollei Infra-Red Filter	Foste	Stereo Attachment
Foerl	Graduated Filter	Fohod	Extension Hood
Batnu	Rolleisoft 0	Aumek	Auxiliary Focusing Knob (meter) with Film Indicator
Baton	Rolleisoft 1		
Batar	Rolleipol	Aukfe	Auxiliary Focusing Knob (feet) with Film Indicator
Bapun	Rolleinar Lenses, set 1 (40-18 in.)	Blika	Connecting Cord for Flash Attachment 16 in.
Baodo	Rolleinar Lenses, set 2 (20-12 in.)	Blilo	Connecting Cord for Flash Attachment 80 in.
Baken	Rolleipar Lens 1		
Bakdu	Rolleipar Lens 2		

To avoid errors when ordering accessories please specify camera-number.

Full information on the use of Rollei accessories in the booklet "The Practical Accessories".

Table of Rollei Filters

Rollei Filter	Use	Filter Factor Ortho	Filter Factor Pan
Sport Filter	For sports and short exposures. A very light yellow filter (see below).	2 x	1.5 x
Light yellow	Landscapes, snow, clouds. Renders yellow and green lighter, blue darker.	3 x	2 x
Medium yellow		4 x	3 x
Light green		3 x	2 x
Green	Landscapes, snow, clouds. Renders green lighter, red (complexion) and blue darker. For pan emulsions.	4 x	3 x
Orange	Hazy distant views. Renders yellow-red lighter, blue darker, distant objects clearer.		4-7 x
Light red	Hazy distant views. Renders red lighter, blue-green darker. Gives stronger effects than Orange Filter.		4-10 x
Light blue	Artificial light. Renders red darker. For ultra-pan emulsions.		1.5 x
UV	High altitudes above 6000 feet. Seascapes. Eliminates ultra-violet rays which impair definition.	1.5 x	1.5 x
Infra-Red	Special filter for infra-red emulsions. Transmits dark red above 700 m μ and infra-red.	*)	
H 1	UV-Filter, especially designed for long distance color photography. Absorbs ultra-violet rays, subdues predominance of blue and cuts aerial haze in distance shots.	No increase of exposure	
Graduated Filter	A yellow filter of gradually increasing density, for filtering the sky only in landscapes.	Expose for the landscape	

*) Exposure depends on the type of emulsion used and must be determined by tests.

Focal Length and Focusing-Range with Rolleinar Lenses

Rolleinar Lenses	1		2	2+1	2+2
Focal Length	75 mm	71 mm	68 mm	65 mm	63 mm
Focusing-Range (in inches)	∞-32	$39\frac{1}{2}-17\frac{3}{4}$		$19\frac{3}{4}-12\frac{1}{8}$	$13-9\frac{7}{8}$
					$9\frac{7}{8}-7\frac{1}{8}$

Field-Size and Scale of Reproduction

Focused Distance	$31\frac{1}{2}$ in.	$19\frac{3}{4}$ in.	13 in.	$9\frac{7}{8}$ in.	$7\frac{1}{8}$ in.
Field-Size (in Rolleinar inches)	22×22	$13\frac{3}{4} \times 13\frac{3}{4}$	$8\frac{3}{4} \times 8\frac{3}{4}$	$6\frac{1}{4} \times 6\frac{1}{4}$	$4\frac{3}{4} \times 4\frac{3}{4}$
	$9 \times 12\frac{1}{2}$	$5\frac{1}{2} \times 7\frac{7}{8}$	$3\frac{1}{2} \times 5\frac{1}{8}$	$2\frac{3}{4} \times 3\frac{1}{2}$	$2 \times 2\frac{3}{4}$
Scale of Reproduction approx.	1:10	1:6.3	1:3.9	1:2.9	1:2.2

Depth of Field with Rolleinar Lenses

Rolleinar	1		2	2+1	2+2	f/Stop
Focused Distance (in inches)	$31\frac{1}{2}$	$23\frac{1}{2}$	$19\frac{3}{4}$	$15\frac{3}{4}$	$11\frac{3}{4}$	$7\frac{7}{8}$
from to	$29\frac{1}{2}$ to $33\frac{1}{2}$	$22\frac{1}{2}$ to $24\frac{3}{4}$	$18\frac{7}{8}$ to $20\frac{1}{2}$			5.6
from to	$28\frac{3}{4}$ to $34\frac{1}{4}$	$22\frac{1}{4}$ to $25\frac{1}{4}$	$18\frac{3}{4}$ to $20\frac{7}{8}$	$15\frac{1}{8}$ to $16\frac{1}{2}$	$11\frac{3}{8}$ to $12\frac{1}{8}$	8
from to	28 to $35\frac{3}{4}$	$21\frac{5}{8}$ to 26	$18\frac{1}{8}$ to $21\frac{1}{4}$	15 to $16\frac{7}{8}$	$11\frac{1}{4}$ to $12\frac{3}{8}$	11
from to	$26\frac{3}{4}$ to $38\frac{1}{4}$	$20\frac{7}{8}$ to $27\frac{1}{4}$	$17\frac{3}{4}$ to 22	$14\frac{5}{8}$ to $17\frac{1}{4}$	11 to $12\frac{5}{8}$	16
Depth of Field (in inches)	$25\frac{1}{4}$ to $41\frac{3}{4}$	20 to $28\frac{3}{4}$	$16\frac{7}{8}$ to $23\frac{1}{4}$	$14\frac{1}{4}$ to $18\frac{1}{8}$	$10\frac{3}{4}$ to 13	22

Taking-distance measured from lens panel to object. Permissible circle of confusion in this special case (due to the large image and less need for enlarging) = $f/1000$. For increased sharpness further stopping down is required.

FRANKE & HEIDECKE

BRAUNSCHWEIG

Rolleiflex Rolleicord



Printed in Germany

0852

F. B.

U